

# USER MANUAL

## ***E531 Series***

*Scalable Industrial PC*



## Technical Support and Service

If user need technical support, please contact the local distributor or seller. Before consulting, please collect the following information:

- Product name and serial number
- Collect all information about the problem encountered
- Software used (operating system, version, application software, etc.)
- A complete description of the problem with the product
- Full content of each error message

## Safety Measures - Static Electricity Protection

Please follow the following simple precautions before using the equipment to protect yourself and your products from harm:

- Before using the computer, be sure to disconnect the power supply to avoid the risk of electric shock. Do not touch the CPU or any components on the board while the computer is turned on.
- Disconnect the power supply before making any hardware configuration changes. A sudden electric shock while connecting a jumper or installing the board/card can damage sensitive electronic components.

## Safety Tips

- 1) Please read this safety instruction carefully;
- 2) Please keep this user manual for future reference;
- 3) Remove the power cable before cleaning the device with a damp cloth. Do not use liquid cleaning agent to clean the PC;
- 4) Do not use the PC in a humid environment;
- 5) Before installation, ensure that the device is placed on a horizontal plane. An accidental fall may cause damage to the device;
- 6) The computer case is used for convection heat dissipation, in order to prevent the equipment from overheating, please do not cover any objects;
- 7) Before you power on the equipment, please confirm whether the power supply voltage meets the requirements;
- 8) Please arrange the power cord in a position that is not easy for people to trip, and do not pile any debris on the power cord;
- 9) Pay attention to all warning signs on the device;
- 10) If you do not use the equipment for a long time, please disconnect the power supply to avoid the computer being damaged by excessive voltage fluctuations;
- 11) Do not let any liquid flow into the power port or external interface to avoid short circuit and cause fire;
- 12) Please do not turn on the computer yourself. To ensure your safety, turn on the device by a certified engineer;
- 13) Do not place the device in an environment beyond the recommended temperature range; otherwise, the device may be damaged.
- 14) The device is equipped with a real-time clock circuit powered by a battery. If the battery is not replaced correctly, there is a danger of explosion. Therefore, only batteries of the same type or equivalent model recommended by the manufacturer can be replaced. Please dispose of old batteries according to the manufacturer's instructions;
- 15) Note: Any unverified parts can cause accidental damage to the equipment. To ensure correct installation, please only use the parts provided in the accessory box, such as screws;
- 16) Note: Whenever you perform hardware operations, be sure to completely disconnect the

chassis from the power supply. Do not connect the device while the power is on to avoid damage to sensitive electronic components by a transient surge. Please turn on the device by a professional.

17) In the following cases, please be repaired by a professional:

- a. The power cord or plug is damaged;
- b. There is liquid flowing into the device;
- c. The device has been used in excessively humid environments;
- d. Device does not work properly;
- e. Damage caused by falling equipment;
- f. The appearance of the device is damaged.

## Using Tips

1) To avoid unnecessary damage to the device caused by frequent switching on and off in a short period of time, wait at least 30 seconds after shutdown before turning on the device.

2) Please use the power supply that meets the requirements or the adapter provided by the manufacturer. Otherwise, the startup exception, the image is not displayed, and unstable running may occur. Do not use the power supply exceeding the applicable voltage to supply power to the device. Otherwise, the device may be damaged.

# Catalogue

1.	Overview .....	7
	<b>1.1 Introduction</b> .....	7
	<b>1.2 Safety precautions</b> .....	7
	<b>1.3 Specifications</b> .....	7
	1.3.1 Processor System .....	8
	1.3.2 External I/O.....	8
	1.3.3 PCIe Expansion Slots .....	8
	1.3.4 Internal Connectors.....	9
	1.3.5 Switch & LED Indicator.....	9
	1.3.6 Power .....	9
	1.3.7 Physical Characteristics .....	9
	1.3.8 Environment.....	10
	1.3.9 Others.....	10
	1.3.10 Certification .....	10
	<b>1.4 Packing List</b> .....	10
	1.4.1 Appearance & Dimension.....	11
2.	Interfaces Description.....	12
	<b>2.1 External IO</b> .....	13
	2.1.1 Power Connector 1.....	13
	2.1.2 DP .....	13
	2.1.3 VGA .....	14
	2.1.4 Ethernet (LAN).....	14
	2.1.5 USB 3.0.....	15
	2.1.6 USB 2.0.....	15
	2.1.7 Serial Port (COM1&COM2) .....	16
	2.1.8 PCIe/PCI Expansion Slot .....	16
	2.1.9 Power Connector 2 (Power to Graphic Card).....	17
	2.1.10 Remote.....	17
	2.1.11 Audio.....	17
	2.1.12 Power Button.....	18
	2.1.13 Reset .....	18
	2.1.14 LED Indicator .....	18
	2.1.15 Grounding Requirements.....	19
3.	Operating instructions.....	20
	<b>3.1 Unpacking Inspection</b> .....	20
	<b>3.2 Working Environment</b> .....	20

<b>3.3 Preparation</b> .....	20
<b>3.4 Installation Steps</b> .....	21
3.4.1 Hardware Connection .....	21
3.4.2 Gigabit network card camera configuration.....	21
3.4.3 Several parameters that need to be adjusted during image acquisition....	22
<b>3.5 System Protection</b> .....	22
3.5.1 System repair .....	22
3.5.2 System Backup .....	22
3.5.3 C disk protection .....	22
<b>4. BIOS Setup Instruction</b> .....	<b>24</b>
<b>4.1 BIOS Description</b> .....	24
4.1.1 Enter CMOS Setup.....	25
4.1.2 Function Keys and Auxiliary Instructions .....	25
<b>4.2 Main Menu Function</b> .....	26
<b>4.3 Main (Standard CMOS Function Settings)</b> .....	27
<b>4.4 Advanced (Advanced BIOS Function Settings)</b> .....	28
<b>4.5 Chipset (Chipset Performance Settings)</b> .....	29
<b>4.6 Security (Set administrator/user password)</b> .....	30
<b>4.7 Boot (Boot Settings)</b> .....	31
<b>4.8 Save &amp; Exit</b> .....	32
<b>5. Troubleshooting Guide</b> .....	<b>34</b>
<b>5.1 Abnormal startup</b> .....	34
<b>5.2 System crashes or blue screen during operation</b> .....	35
<b>5.3 Unable to install device driver correctly</b> .....	35
<b>5.4 BIOS Upgrade</b> .....	35

# 1. Overview

This chapter mainly introduces the E531 series products briefly, and gives a detailed list of machine parameters. For different series of products, the corresponding appearance size diagram and a simple description of the indicator light are given.

## 1.1 Introduction

E531 series embedded industrial computer is a high-performance industrial computer which can meet the needs of various machine vision scenarios. Based on Intel® 6<sup>th</sup>~9<sup>th</sup> generation Core™ series high performance processors, the E531 is powerful with a multi-core processor that supports up to 32GB of DDR4 memory for fast response at all times.

E531 series industrial computer has rich IO interfaces, provides 3 GbE LAN, 1 RS-232/422/485, 2 RS-232/485, 3 RS-232, 4 USB3.0, 4 USB2.0, and 1x PCIe 2.0 4 slot (x2 signal), 1x PCIe 3.0 x16 slot support graphics card up to RTX 4080.

E531 series industrial computers are suitable for semiconductor inspection, 3C electronics manufacturing, food sorting, automotive manufacturing and other industries, equipped with machine vision products, intelligent manufacturing and smart factories to enable the core control unit for the full solution.

## 1.2 Safety precautions



1. *Before performing any operation, remove the power cable from the chassis. Do not connect the chassis when the system power is on. A sudden surge of current may damage sensitive electronic components. Opening the chassis requires experienced personnel to operate.*
2. *Before touching the E531, be sure to ground yourself to eliminate static electricity and wear an ESD bracelet. Modern electronic devices are very sensitive to electrostatic charges, so place all electronic components on an electrostatic dissipating surface or in an electrostatic shielding bag.*

## 1.3 Specifications

### 1.3.1 Processor System

<b>Table 1-1</b>	<b>Processor System</b>
<b>CPU</b>	6 <sup>th</sup> to 9 <sup>th</sup> Gen Intel® Core™ i3/ i5/ i7 series CPU
<b>BIOS</b>	AMI 128Mbit SPI Flash
<b>Memory</b>	2 x DDR4 SO-DIMM up to 32GB

### 1.3.2 External I/O

<b>Table 1-2</b>	<b>External IO</b>
<b>DP</b>	2 x DP up to 4096 x 2304@60Hz
<b>VGA</b>	1 x VGA up to 1920 x 1080@60Hz
<b>Ethernet</b>	2 x Intel i210 GbE LAN, 1 x Intel i219 GbE LAN
<b>Serial Port</b>	1 x RS-232/422/485, 2 x RS-232/485, 3 x RS-232
<b>USB</b>	4 x USB 3.0, 4 x USB 2.0
<b>Power Connector 1</b>	1 x 3 PIN Phoenix terminal (Power to the PC)
<b>Power Connector 2</b>	1 x 4 PIN Phoenix terminal (Power to the graphic card)

### 1.3.3 PCIe Expansion Slots

<b>Table 1-3</b>	<b>PCIe Expansion Slots</b>
<b>PCIe x16</b>	1 x PCIe 3.0 x16
<b>PCIe x4</b>	1 x PCIe 2.0 x4 (x2 signal)

### 1.3.4 Internal Connectors

<b>Table 1-4</b>	<b>Internal Connectors</b>
<b>Mini PCIe</b>	1 x full-size Mini-PCIe, with WLAN/WWAN module support
<b>M.2 B/M-Key</b>	1 x M.2 2280 SATA3.0
<b>SATA 3.0</b>	1 x SATA 3.0
<b>USB2.0 (Internal)</b>	1 x USB 2.0 Type-A support Dongle
<b>SIM</b>	1 x Nano SIM

### 1.3.5 Switch & LED Indicator

<b>Table 1-5</b>	<b>Switch &amp; LED Indicator</b>
<b>Power Button</b>	1 x Power Button
<b>Reset Button</b>	1 x Reset Button
<b>LED Indicator</b>	DG / Stand by / SSD / Watchdog

### 1.3.6 Power

<b>Table 1-6</b>	<b>Power</b>
<b>Power Input</b>	DC 24V
<b>Max Consumption</b>	150W
<b>Power Management</b>	AT/ATX

### 1.3.7 Physical Characteristics

<b>Table 1-7</b>	<b>Physical Characteristics</b>
<b>Dimension</b>	220 x 360 x 176mm (L x W x H)
<b>Weight</b>	5.0 Kg
<b>Installation</b>	Wall-mounting

### 1.3.8 Environment

<b>Table 1-8</b>	<b>Environment</b>
<b>Temperature</b>	Operating Temperature: 0~50°C (32~122°F) Storage Temperature: -40~85°C (-40~185°F)
<b>Humidity</b>	Operating Humidity: 95% @ 40 °C (Non-condensing) Storage Humidity: 95% @ 60 °C (Non-condensing)

### 1.3.9 Others

<b>Table 1-9</b>	<b>Others</b>
<b>Watchdog</b>	Interrupt, System Reset 255 levels timer interval, from 1 to 255 sec

### 1.3.10 Certification

<b>Table 1-10</b>	<b>Certification</b>
<b>EMC</b>	CE, FCC

## 1.4 Packing List

When unpacking the box, check the accessories for obvious damage and confirm whether the random accessories are consistent. For details about accessories, see Table 1-11.

<b>Table 1-11</b>	<b>Packing List</b>
<b>1</b>	E531 Series Industrial PC x1
<b>2</b>	Screw x6
<b>3</b>	Three plug power cord x1
<b>4</b>	Power supply, 120W 24V 5A
<b>5</b>	Wall mounting kits x1

## 1.4.1 Appearance & Dimension

The dimension of E531 is 220 x 360 x 176mm, Figure 1-1 shows the appearance and installation dimensions.




Figure 1-1 Dimension of the E531

## 2. Interfaces Description

This chapter mainly introduces the peripheral interfaces of E531 series industrial computers, and describes the pins of some of them in detail, which can provide a reference for the user's connection use. Interfaces of the E531 are shown in the following figure.




Figure 2-1 I/O of the E531

Interfaces			
1	2* COM	8	VGA
2	2* DP	9	4* COM
3	3* LAN	10	2* USB 2.0
4	Audio	11	Remote
5	LED Indicator	12	4* USB 3.0, 2* USB 2.0
6	Power Button	13	Power Connector 2 (Power to graphic card)
7	Power Connector 1 (Power to the PC)		

## 2.1 External IO

### 2.1.1 Power Connector 1




Figure 2-1 Power Connector 1

The E531 is equipped with a 3 PIN Phoenix terminal power port that supports 24V DC input. For the PIN definition, see Table 2-1.

Table 2-1	PIN definition of Power Connector 1
<b>PIN 1</b>	V-
<b>PIN 2</b>	GND
<b>PIN 3</b>	V+

### 2.1.2 DP




Figure 2-2 DP

E531 is equipped with 2 DP port, supports a resolution up to 4096 x 2304@60Hz. Table 2-2 describes the pin definition of the DP port.

PIN	Signal	PIN	Signal
1	D0+	11	GND
2	GND	12	D3-
3	D0-	13	DP_AUX_E#
4	D1+	14	GND
5	GND	15	AUX+
6	D1-	16	GND
7	D2+	17	AUX-
8	GND	18	HPD
9	D2-	19	GND
10	D3+	20	+3.3V

## 2.1.3 VGA




Figure 2-3 VGA

E531 is equipped with a VGA, supports a resolution up to 1920 x 1080@60Hz. Table 2-3 describes the pin definition of the VGA.

Table 2-3		PIN definition of VGA	
<b>PIN 1</b>	RED	<b>PIN 9</b>	KEY
<b>PIN 2</b>	GREEN	<b>PIN 10</b>	GND
<b>PIN 3</b>	BLUE	<b>PIN 11</b>	ID0
<b>PIN 4</b>	ID2	<b>PIN 12</b>	ID1
<b>PIN 5</b>	GND	<b>PIN 13</b>	HSYNC
<b>PIN 6</b>	RGND	<b>PIN 14</b>	VSYNC
<b>PIN 7</b>	GGND	<b>PIN 15</b>	ID3
<b>PIN 8</b>	BGND		

## 2.1.4 Ethernet (LAN)




Figure 2-4 LAN

The E531 series has 2 Ethernet ports controlled by independent Intel i210 chip and 1 Ethernet port controlled by an Intel i219 chip, supporting 10/100/1000 Mbps; 3 ports with standard RJ-45 jacks. In addition, each Ethernet port also has LED indicators to indicate the connection and transmission status. The Link indicator is on when the network port is connected, and the ACT indicator is blinking when the network port has data transmission. Table 2-4 describes the pin definitions of LAN interfaces.

PIN	Signal	PIN	Signal
1	TX+	5	MDI2-
2	TX-	6	RX-
3	RX+	7	MDI3+
4	MDI2+	8	MDI3-

## 2.1.5 USB 3.0




Figure 2-5 USB3.0

The E531 series supports 4 USB3.0 ports, which can be connected to the USB 3.0 HD camera, supports the plug and play and hot swap functions of external devices, allowing users to connect or disconnect the device at any time.

PIN	Signal	PIN	Signal
1	+5V	5	USB0_SSRX-
2	D-_0	6	USB0_SSRX+
3	D+_0	7	GND
4	GND	8	USB0_SSTX-
		9	USB0_SSTX+

## 2.1.6 USB 2.0




Figure 2-6 USB2.0

The E531 series supports 4 USB 2.0 ports, and supports the plug and play and hot swap functions of external devices, allowing users to connect or disconnect devices at any time. For details about pin definitions of USB2.0 ports, see Table 2-6.

PIN	Signal
1	VCC
2	USB_data-
3	USB_data+
4	GND

## 2.1.7 Serial Port (COM1&COM2)




Figure 2-7 COM

E531 has 6 DB9 COM, 1 x RS-232/422/485, 2 x RS-232/485, 3 x RS-232, which can communicate with multiple devices. Figure 2-7 shows the ports.

Table 2-7	PIN definition of COM		
	RS-232	RS-422	RS-485
<b>PIN1</b>	DCD	Tx-	DATA -
<b>PIN2</b>	RXD	Tx+	DATA+
<b>PIN3</b>	TXD	Rx+	NC
<b>PIN4</b>	DTR	Rx-	NC
<b>PIN5</b>	GND	GND	GND
<b>PIN6</b>	DSR	NC	NC
<b>PIN7</b>	RTS	NC	NC
<b>PIN8</b>	CTS	NC	NC
<b>PIN9</b>	RI	NC	NC

## 2.1.8 PCIe/PCI Expansion Slot




Figure 2-8 PCIe/PCI Expansion Slot

E531 provides 2 PCIe/PCI slots (1 PCIe 3.0 x16, 1 PCIe 2.0 x4 (x2 signal)), which can support graphic cards up to RTX 4080.

## 2.1.9 Power Connector 2 (Power to Graphic Card)



Figure 2-9 Power Connector 2

E531 equipped with a 4 PIN Phoenix terminal power connector that can power to graphic card, support 24V DC input. For the pin definition of the connector, see Table 2-9.

Table 2-8	PIN definition of Power Connector 2
PIN 1	-
PIN 2	+
PIN 3	+
PIN 4	-

## 2.1.10 Remote




Figure 2-10 Remote

E531 has a remote switch, the pin definition please refer to Table 2-10.

Table 2-9	PIN definition of Remote
PIN 1	PWR
PIN 2	GND
PIN 3	GND
PIN 4	3.3V+

## 2.1.11 Audio




Figure 2-11 Audio

The E531 series has two 3.5 stereo audio ports for Line-out and Mic-in. Figure 2-11 shows the ports.

## 2.1.12 Power Button



Figure 2-12 Power Button

The E531 series is equipped with a power button to control computer on and off.

## 2.1.13 Reset



Figure 2-13 Reset

There is a reset button on the E531. Press it to restart the system.

## 2.1.14 LED Indicator





Figure 2-144 LED Indicator

E531 series front panel has 4 LED indicators, the indicator status is described as follows:

Table 2-10	Status indication	LED Status Description
<b>DG</b>	Memory Indicator	Yes: Light off / None: Light on
	Standby indicator	Standby: Flashing / Work: Light off
	SATA SSD detection	Working: Flashing / Yes: Light on / None: Light off
<b>WD</b>	Watchdog indicator	Working: Light on / Stop: Light off

## 2.1.15 Grounding Requirements

There is a grounding position on the side of the machine (⚡). Use a grounding wire as thick and short as possible (with a wire length of less than 30 cm) to ground the machine. The grounding end adopts a round-head screw, and the tightening torque is 0.55~0.8 N•m. The grounding schematic diagram is as follows:



- ① Round-head screw
- ② Grounding Wire
- ③ Grounding screw hole

# 3. Operating instructions

This chapter describes the normal operation of E531 series products, describes the working environment of industrial computers, installation procedures, and detailed operation of system protection functions.

## 3.1 Unpacking Inspection

Before opening the package, please check whether the product model indicated on the outer package is consistent with the ordered product. After opening the package, please first check the surface of the computer for mechanical damage, and then carefully check whether the accessories are complete according to the packing list or order contract. If the surface of the computer is damaged or the product content does not conform, please do not use it and contact the dealer immediately.



To prevent the computer from being damaged by static electricity, please touch effectively grounded metal objects before touching the computer circuit to release the static charge carried by the body, and wear anti-static gloves.

## 3.2 Working Environment

- 1) Computers need to be far away from commercial electrical appliances and environments with high power and strong electromagnetic interference;
- 2) The working ambient temperature shall be between 0°C and 50°C;
- 3) The power supply voltage shall be kept between 200V and 240V.

## 3.3 Preparation

Please prepare the following items before installation:

- 1) E531 series industrial computers, as well as related power supplies and cables;
- 2) Display, and display connecting line between display and IPC;
- 3) USB Keyboard and Mouse;
- 4) PLC, Camera and corresponding connecting line;
- 5) Power supply.

## 3.4 Installation Steps

### 3.4.1 Hardware Connection

- 1) Connect the computer to the display with DP or VGA cable;
- 2) Connect the computer power cable and the USB port to the keyboard and mouse;
- 3) Connect other hardware such as PLC and camera according to corresponding interface
- 4) Connect the power adapter to 220V voltage and start it.

### 3.4.2 Gigabit network card camera configuration

- 1) Confirm that the camera is connected to the power supply and that the camera is connected to the industrial computer with a network cable

- 2) Turn off firewall

Control panel -> Windows Defender -> set up -> Implementation of protection -> Remove tick and administrator -> Start Windows Defender -> Remove tick.

- 3) Open camera software

- 4) Advanced network settings

Device Manager -> network adapter -> attribute -> dispose -> Advanced Page, Set the value of "Jumbo Packet" to the maximum value of "9014 Bytes"; Select the attribute of "Internet Protocol Version 4 (TCP/IPv4)" in the Ethernet attribute, and set its IP address to the address in the same network segment as the camera IP address, as shown in Figure 3-1.




Figure 3-1 Diagram of advanced Network Settings

### 3.4.3 Several parameters that need to be adjusted during image acquisition

Packet Size parameter setting: This parameter unit is bytes, and should be set to a parameter close to the network card's giant frame parameter as much as possible, for example, giant frame=9K, and the Packet Size of the camera software should be set to 8000 or close to 9K. Click the continue shot in Pylon viewer. The rule is to see that the camera can achieve full frame rate acquisition until the Packet Size is set to the larger the better (not exceeding the megafame size), which can effectively reduce the CPU utilization.

## 3.5 System Protection

### 3.5.1 System repair

A hidden space (A disk) is allocated in the E531 series industrial computer to store the backup system. Users can repair the system through simple operation.

- 1) Power on the industrial computer and press "F8" to enter the repair mode;
- 2) Select "Repair Computer", enter startnet.cmd, type "0" according to the prompt, and press Enter to start the system repair (system repair is generally a backup system. If there is no backup in advance, the default is a pure system. After repair, the file is not retained, which is equivalent to reinstalling the system)

### 3.5.2 System Backup

E531 series industrial computers are allocated with a hidden space (A disk) to store the backup system. Users can backup the system independently through simple operation.

- 1) Power on the industrial computer and press "F8" to enter the repair mode;
- 2) Select "Repair the computer", enter startnet.cmd, type "1" according to the prompt, and press Enter to start the backup of the system (the backup system is the content of the current system, please note that the size of the system should not exceed 15G)

### 3.5.3 C disk protection

E531 series industrial computers are preinstalled with C\_Protect program. Users can choose to enable or disable the C disk protection according to requirements (the default is disabled).

- 1) Enter C in the root directory of C disk folder\_ The file shown in Figure 3-2 can be seen in the Protect folder.




Figure 3-1 C disk protection program

- 2) If you want to turn on the C disk protection, right click "Enable" to run as an administrator. Do not do anything during the process until the machine is restarted.
- 3) When the C disk protection is on, if you want to close the C disk protection program, right click "Disable" to run as an administrator. Do not do anything during the process until the machine is restarted.

Note: The C disk protection program is only valid for the contents of the C disk (including the desktop content). When the C disk protection is enabled, all additions, deletions, and changes to the C disk will not be saved. Therefore, if you need to modify the programs or files in the C disk, you need to cancel the C disk protection first.

# 4. BIOS Setup Instruction

## 4.1 BIOS Description

BIOS is a basic input and output control program stored in Flash Memory. It is a bridge between the motherboard and the operating system and is responsible for managing the relevant parameter settings between the motherboard and the expansion card. When the computer is activated, it will be controlled by the BIOS program. First, a self-test called POST will be executed. It will detect all hardware devices and confirm the synchronization hardware parameters; When all the tests are completed, it will transfer the control of the system to the operating system (OS). Because BIOS is the only channel between hardware and software, how to properly set the parameters in BIOS will determine whether your computer runs stably and works in the best state. Therefore, the correct setting of BIOS is the key factor of system stability, thus ensuring that the system performance can reach the best state.

CMOS Setup will store the set data in the built-in CMOS SRAM on the motherboard. When the power is turned off, the lithium battery on the motherboard continues to supply power to the CMOS SRAM. The BIOS setup utility allows you to configure:

- 1) Hard drives and peripherals
- 2) Video display type and display options
- 3) Password protection
- 4) Power management features



*For the BIOS version of the motherboard is constantly upgraded, the description of BIOS in this manual is for reference only. We do not guarantee the consistency between the relevant contents in this manual and the information you have obtained.*

### 4.1.1 Enter CMOS Setup

When the computer starts, the BIOS enters the power-on self-test (Post) program. The self-test program is a series of diagnostic programs fixed in the BIOS. When the self-test program is completed, no errors are encountered. If you want to enter the BIOS, press the DEL key or ESC key until you enter the BIOS interface. If this message disappears before you respond, you can turn off and restart your computer, or press <Ctrl>+<Alt>+<Delete> to restart your computer at the same time.

### 4.1.2 Function Keys and Auxiliary Instructions

↑ (Up arrow)	Used to move to the previous item
↓ (Down arrow)	Used to move to the next item
← (Left arrow)	Used to move to the left item
→ (Right arrow)	Used to move to the right item
ESC	Used to exit the current screen
Enter	Used to selection confirmation
+	Used to change the setting state or increase the value content
—	Used to change the setting state or decrease the value content
F1	Used to display help
F2	Used to load the last set value
F3	Value for loading optimization
F4	Used to save the set value and leave the CMOS SETUP program

Auxiliary description of main screen:

When you are in the Setup main screen, as the options move, the main settings of the corresponding options are displayed below.

If you want to leave the auxiliary instruction window, just press the [ESC] key.

## 4.2 Main Menu Function

When you enter the CMOS setup setting menu, you can see the main menu shown in Figure 4.1 at the top of the screen. In the main menu, you can select different setting options by pressing the left and right direction keys. After selecting the submenu, the detailed setting options will be displayed below.




Figure 4-1 Main menu

1) Main (Standard CMOS Function Settings)

Set date, time, etc.

2) Advanced (Advanced BIOS Function Settings)

Set special functions provided by BIOS, such as CPU, USB, PCI, network port, etc.

3) Chipset(Chipset Performance Settings)

Set North Bridge、 South Bridge, etc.

4) Security (Set administrator/user password)

5) Boot (Launch configuration feature)

6) Save & Exit

This option includes discard changes/exit without saving/exit without saving, etc.

## 4.3 Main (Standard CMOS Function Settings)




Figure 4-2 Main menu

1) System Time(hh:mm:ss) (Time setting)

Set the time in the computer in the format of "hour/minute/second"

2) System Date(mm:dd:yy) (Date setting)

Set the date in the computer in the format of "month/day/year"

## 4.4 Advanced (Advanced BIOS Function Settings)




Figure 4-3 Advanced Menu

- 3) CPU Configuration
- 4) Power & Performance
- 5) Trusted Computing
- 6) ACPI Settings
- 7) Super IO Configuration
- 8) Hardware Monito
- 9) Smart Fan Function
- 10) Watch Dog Configuration
- 11) IT8786ESEC Super IO Configuration
- 12) S5 RTC Wake settings
- 13) USB Configuration
- 14) CSM Configuration
- 15) SDIO Configuration

## 4.5 Chipset (Chipset Performance Settings)




Figure 4-4 Chipset Menu

- 1) System Agent (SA) Configuration
- 2) PCH-IO Configuration

## 4.6 Security (Set administrator/user password)




Figure 4-5 Security Menu

- 1) **Administrator Password:** Set the superuser password option, which has the highest permissions. When you select this function, the following message will appear: `Crate New Password*****`  
Enter a password of up to twenty characters, and then press the <Enter> key. BIOS requires to enter the same password again. After entering, BIOS saves the set password. Once you use the password function, you will be asked to enter the password before entering the BIOS setup program each time. This can prevent any unauthorized person from using your calculation.
- 2) **User Password:** Set the user password option. This password permission will be restricted and some settings cannot be changed.  
When you select this function, the following message will appear: `Crate New Password*****`  
Enter a password of up to twenty characters, and then press the <Enter> key. BIOS requires to enter the same password again. After entering, BIOS saves the set password. Once you use the

password function, you will be asked to enter the password before entering the BIOS setup program each time.

## 4.7 Boot (Boot Settings)




Figure 4-6 Boot Menu

### 1) Boot Configuration

#### Setup Prompt Timeout:

The POST dwell time is displayed when the machine is turned on. The larger the value, the longer the dwell time.

#### Bootup NumLock State:

The setting values are: [On]/[Off]. This option specifies the state of the Num Lock key on the keyboard after the computer is started.

#### Quiet Boot:

The setting values are: [Disabled]/[Enabled]. This option specifies whether to display LOGO when the computer starts.

### 2) Boot Option Priorities

Boot Option #1: First startup option

Boot Option #2: Second startup option

Boot Option #3: Third startup option

Fast Boot:

The setting values are: [Disabled]/ [Enabled]

### 3) Hard Drive BBS Priorities

## 4.8 Save & Exit




Figure 4-7 Save & Exit Menu

### 1) Save Options

Save Changes and Reset

Discard Changes and Reset

### 2) Restore Defaults

Restore Defaults: Load Optimal Defaults

This option in the main menu allows the user to restore all BIOS options to the optimized value.

The optimization default value is the default value set to optimize the performance of the motherboard. If you select YES and press Enter, you can save all the setting results to CMOS

SRAM and leave the BIOS setting program; If you do not want to save, select NO to return to the main menu.

Save as User Defaults

# 5. Troubleshooting Guide

## 5.1 Abnormal startup

- 1) After pressing the power button to turn on the machine, the power indicator does not light up
  - a) Check whether the industrial computer is connected correctly and whether the power socket is powered;
  - b) Check the industrial computer power adapter, plug and unplug the power cable, display data cable and keyboard and mouse cable, Confirm whether the connection between the display and the host is correct;
  - c) Check whether the positive and negative poles of the power plug are reversed.
- 2) The power indicator is on, but the display does not display
  - a) Check the power supply and switch of the display;
  - b) Check whether the data line of the display has poor contact;
  - c) If DisplayPort or VGA converter is used, replace the converter of other brands;
  - d) Observe the keyboard and mouse indicators. If the keyboard indicators and mouse indicators are on, replace the display for troubleshooting.
- 3) After power-on, the motherboard fails to self-check successfully  
Press the [Del] key to reset CMOS or clear CMOS.
- 4) The mouse and keyboard cannot be used after power-on
  - a) Check whether the keyboard lock is locked and release the keyboard lock;
  - b) If not, check whether the connection between the motherboard and the backplane and whether the keyboard and mouse are connected correctly;
  - c) Check whether the keyboard and mouse are connected to the one-in-two adapter. If yes, connect the keyboard and mouse in reverse;
  - d) Replace one split and two connectors;
  - e) Replace the mouse and keyboard.
- 5) Unable to boot the system from the hard disk after power-on
  - a) Press "Del" key to check whether the parameter setting and boot sequence of CMOS hard disk are correct;
  - b) After booting with optical drive or floppy drive, check whether the hard disk has a boot system or whether the hard disk is properly partitioned and has activated boot Zoning;
  - c) When starting, press F8 to select the last correct configuration to start the operating system;
  - d) Replace the hard disk and reinstall the system.

## 5.2 System crashes or blue screen during operation

- 1) Check whether the temperature of industrial computer is too high;
- 2) Check whether the wrong or expired driver is installed;
- 3) Check whether the system is infected with virus;
- 4) Whether the system files or applications and disks are damaged.

## 5.3 Unable to install device driver correctly

- 1) Check whether the driver is correct and up-to-date;
- 2) Whether the driver needs the support of the patch of the operating system;
- 3) Whether the resources occupied by other devices conflict with those occupied by the devices to be driven;
- 4) If it is a peripheral device, change a slot and reinstall the drive;
- 5) Replace the device and reinstall the driver.

## 5.4 BIOS Upgrade

- 1) Prepare a UEFI startup USB flash disk. If not, you need to make one;
- 2) Please copy the required BIOS file and batch processing to the root directory of the USB flash drive;
- 3) Press F7 to start the machine, select the prepared UEFI USB flash disk, and press Enter to enter the shell;
- 4) Enter FS0: Enter (fs0: if no other storage device is connected);
- 5) Run flash.nsh, brush BIOS, and do not power off in the middle;
- 6) After brushing the BIOS, power off, then power on again, restart the industrial computer, enter the BIOS settings, and press F3 to load the BIOS optimized defaults (Enter to select Y).

The following conditions may cause the refresh to fail and the machine cannot be started.

- 1) Power off during refresh;
- 2) Virus exists in the USB flash drive;
- 3) BIOS file is damaged;
- 4) In non-UEFI system.

**If the BIOS cannot be started after refreshing, you can try to clear the BIOS. If the situation persists, please return to the factory for maintenance.**